


Radiation Hardness Study on Fused Silica

Matthias Hoek
University of Glasgow


6th International Workshop on Ring Imaging
Cherenkov Counters (RICH2007)

Trieste

The PANDA Detector



Irradiation at KVI




Support by R. Ostendorf, KVI



- Proton beam (150MeV)
 - Average stopping power in SiO_2 (SRIM) $4.7\text{MeV}/(\text{g}/\text{cm}^2)$
- Beam size determination
 - LANEX scintillating screen + CCD
 - FWHM $\sim 4\text{mm}$
- Ionisation chamber
 - Beam current between 0.5 and 100nA
 - Max dose of 10Mrad in app 6 min

Samples

- 3 fused silica samples
 - Corning 7980
 - Schott Lithosil Q0
 - Heraeus Suprasil 1
- Estimated dose ~ 100krad
 - Planned dose 10krad, 100krad, 1Mrad and 10Mrad
 - Delivered dose sys 20% higher




Transmission Measurement



Measurements performed
by E. Bennet & E. Cowie

- Cary 300 double beam Spectrophotometer
 - Wavelength between 200 and 800nm
 - Beam spot $2 \times 8 \text{ mm}^2$
 - Precision better than 10^{-3}
 - Wavelength accuracy better than 0.2nm
- Each sample measured before irradiation at 4 spots

Finding Radiation Spots



- Measurements 4 weeks after irradiation
 - Samples stored in light-tight box
- Two scans across sample
 - 2mm steps (determined by beam spot size)
- 10 krad spot not visible due to beam halo
- Remaining spots clearly visible
- Use to adapt sample positioning in spectrophotometer


Sensitivity

- Normalised difference

$$\Delta I = \frac{I_{ref} - I_{sample}}{I_{ref}}$$


→ Compensate for Fresnel loss

- Error sources and contributions
 - Sample positioning
~ 0.1%
 - Sample inhomogeneity
< 0.3%
- Sensitivity better than 1%





Example Analysis of LiF

LiF - 1 & 10 Mrad spots



LiF - 100 & 10 krad spots




LiF


- Only 1 and 10Mrad spot visible
- Transmission measurement reveals two lower dose spots

Fused Silica – Corning 7980

Corning 7980 - 1 & 10 Mrad spots




Corning 7980 - 100 & 10 krad spots




- Sample size $80 \times 80 \times 20 \text{ mm}^3$
 - Radiation spots separated by 40mm
- First and last measurement in a scan influenced by edge effects
- No irradiation spots detected

Fused Silica – Schott Lithosil

Lithosil - 1 & 10 Mrad spots




Lithosil - 100 & 10 krad spots




- Sample size $50 \times 50 \times 15 \text{ mm}^3$
 - Irradiation spots separated by 25mm
- This sample exhibits most homogeneous result of all fused silica samples
- Small deviations around 200nm probably due to cleaning

Fused Silica – Heraeus Suprasil 1

Suprasil - 1 & 10 Mrad spots




Suprasil - 100 & 10 krad spots



- BaBar reported significant transmission loss between 200–300nm for Suprasil Standard (NIM A515(2003) 680)
- Different sample geometry
 - BaBar: 20cm
 - This work: 2cm
 - Expect 5% deviation at 200nm
- No significant damage observed for Suprasil 1

Surface Study

- Zygo GPI XP/D interferometer
 - He-Ne laser at 632.8nm
 - $\lambda/300$ (2σ) resolution
- Check for surface dilatation
 - observed for silicate crown glasses under proton irradiation ($> 1\text{Mrad}$)
(Applied Optics **41**(2002) 678)
- ➔ No significant surface change observed
 - Corning 7980 sample shown



Conclusions

- 3 fused silica types irradiated with 150MeV proton beam
 - 3 established dose levels: 100krad, 1Mrad and 10Mrad
 - Irradiation spots clearly visible in crown glass and LiF
- Transmission behaviour between 200 and 800nm monitored
 - No significant radiation damage observed in any fused silica sample
 - Sensitivity $\sim 0.5\%$
- No surface dilatation observed
- Further activities
 - Neutron damage